






4. Phone call




5. MP3 Player



USB




CARD



SD card: MicroSD, MicroSDHC
Format: FAT32
File Format: MP3, WMA, WAV
Max Songs: 65500

6. Wired - setup



AUX



FAQ


Frequently asked questions
<http://www.trust.com/20419/faq>

Trust International BV
Laan van Barcelona 600
3317DD, Dordrecht, NL


© 17-3-2015 Trust International BV All rights reserved.




Quick Installation Guide
DIXXO - Wireless Speaker



1. Charging



2. Wireless - setup 1/2



Wireless - setup 2/2



Wireless - Troubleshooting



3. Play music

