



XTRFY M42 WIRELESS QUICK START GUIDE



1.



2.




OFF CPI RGB **PGDN**




3.

xtrfy



- 0-25%
- 26-50%
- 51-75%
- 76-100%

🕒 3s



OFF CPI RGB PGDN





OFF

OFF CPI RGB PGDN



ON




OFF CPI RGB PGDN




CPI

- 400
- 800
- 1200
- 1600
- 3200
- 4000
- 7200
- 19000




POLLING RATE


- 125 Hz
- 500 Hz
- 1000 Hz



OFF CPI RGB PGDN





OFF CPI RGB PGDN




OFF CPI RGB PGDN



BRIGHTNESS




OFF CPI RGB PGDN






35



OFF CPI RGB PGDN




= PGDN



LIFT-OFF DISTANCE

● 1 MM

● 2 MM




DEBOUNCE

● 2 MS

● 4 MS


● 8 MS

● 12 MS







FACTORY RESET

⌚ 5 s







WEIGHT BALANCE





REMOVE SHELL







**CHARGE THE MOUSE VIA
COMPUTER USB PORT ONLY**

*FOR THE FULL MANUAL: SCAN THE QR CODE
BELOW OR GO TO [XTRFY.COM/DOWNLOADS](https://xtrfy.com/downloads)*



 SUPPORT@XTRFY.COM

xtrfy