



# XTRFY M4 WIRELESS QUICK-START GUIDE



1.




2.



OFF CPI RGB **PGDN**



3.




● 0-25%

● 26-50%

● 51-75%

● 76-100%

🕒 3 s



OFF CPI RGB PGDN





OFF

OFF CPI RGB PGDN



ON




OFF CPI RGB PGDN




CPI

- 400
- 800
- 1200
- 1600
- 3200
- 4000
- 7200
- 19000




POLLING RATE


- 125 Hz
- 500 Hz
- 1000 Hz



OFF CPI RGB PGDN




OFF CPI RGB PGDN



OFF CPI RGB PGDN




BRIGHTNESS



+




OFF CPI RGB PGDN






35



OFF CPI RGB PGDN




= PGDN



## LIFT-OFF DISTANCE

● 1 MM

● 2 MM




## DEBOUNCE

● 2 MS


● 4 MS

● 8 MS



● 12 MS





## FACTORY RESET






## WEIGHT BALANCE










**REMOVE SHELL**







**CHARGE THE MOUSE VIA  
COMPUTER USB PORT ONLY**

*FOR THE FULL MANUAL: SCAN THE QR CODE  
BELOW OR GO TO [XTRFY.COM/DOWNLOADS](https://xtrfy.com/downloads)*



 [SUPPORT@XTRFY.COM](mailto:SUPPORT@XTRFY.COM)

**xtrfy**