# HP Neverstop Laser 1200 series

## 1

Remove the packing tape. Lift the scanner and the top cover. Remove and recycle the orange plastic handle with the attached black sheet.

2

A4
8.5 x 11 in.

Install the input tray, load paper, and then slide the cover into place over the tray.

Pull out the output bin extension.

3

Plug in the printer. The printer turns on when it is plugged in and can take up to 1 minute to warm up. You will hear a series of noises, which is normal. When the Ready light ⏻ stops blinking, the printer is ready.
Note: Do not press the Power button ⏻ as this will turn off the printer and stop the warm-up process.

4

123.hp.com

Download HP Smart software to complete printer setup.

?

hp.com/support/printer-setup

Trouble getting started?   Find setup information and videos online.

4QD21-90010