

Подходит к моделям:

LEICA

V-LUX 30

V-Lux 20

V-Lux 40

PANASONIC

Lumix DMC-TZ10

Lumix DMC-TZ10K

Lumix DMC-TZ10N

Lumix DMC-TZ10R

Lumix DMC-TZ10S

Lumix DMC-TZ18K

Lumix DMC-TZ18S

Lumix DMC-TZ20

Lumix DMC-TZ20A

Lumix DMC-TZ20K

Lumix DMC-TZ20N

Lumix DMC-TZ20R

Lumix DMC-TZ20S

Lumix DMC-TZ20T

Lumix DMC-TZ22

Lumix DMC-TZ6

Lumix DMC-TZ7

Lumix DMC-TZ8

Lumix DMC-ZR1

Lumix DMC-ZR1A

Lumix DMC-ZR1GK

Lumix DMC-ZR1K

Lumix DMC-ZR1R

Lumix DMC-ZR1S

Lumix DMC-ZR1W

Lumix DMC-ZR3

Lumix DMC-ZR3A

Lumix DMC-ZR3GK

Lumix DMC-ZR3K

Lumix DMC-ZR3N

Lumix DMC-ZR3R

Lumix DMC-ZR3S

Lumix DMC-ZR3T

Lumix DMC-ZS1

Lumix DMC-ZS10A

Lumix DMC-ZS10GK

Lumix DMC-ZS10K

Lumix DMC-ZS10N

Lumix DMC-ZS10R

Lumix DMC-ZS10S

Lumix DMC-ZS10T

Lumix DMC-ZS19K

Lumix DMC-ZS1GK

Lumix DMC-ZS1K

Lumix DMC-ZS1S

Lumix DMC-ZS3

Lumix DMC-ZS3A

Lumix DMC-ZS3GK

Lumix DMC-ZS3K

Lumix DMC-ZS3S

Lumix DMC-ZS5

Lumix DMC-ZS5GK

Lumix DMC-ZS7

Lumix DMC-ZS7GK

Lumix DMC-ZS8GK

Lumix DMC-ZS8K

Lumix DMC-ZS8S

Lumix DMC-ZX1

Lumix DMC-ZX1A

Lumix DMC-ZX1K

Lumix DMC-ZX1R

Lumix DMC-ZX1S

Lumix DMC-ZX1W

Lumix DMC-ZX3

Lumix DMC-ZX3A

Lumix DMC-ZX3K

Lumix DMC-ZX3N

Lumix DMC-ZX3R

Lumix DMC-ZX3S

Lumix DMC-ZX3T