

Подходит к моделям:

PANASONIC

Lumix DMC-FH2	Lumix DMC-FH24	Lumix DMC-FH25
Lumix DMC-FH25A	Lumix DMC-FH25GK	Lumix DMC-FH25K
Lumix DMC-FH25R	Lumix DMC-FH25S	Lumix DMC-FH25V
Lumix DMC-FH27	Lumix DMC-FH27GK	Lumix DMC-FH27K
Lumix DMC-FH27R	Lumix DMC-FH27S	Lumix DMC-FH2A
Lumix DMC-FH2GK	Lumix DMC-FH2K	Lumix DMC-FH2P
Lumix DMC-FH2R	Lumix DMC-FH2S	Lumix DMC-FH4
Lumix DMC-FH4GK	Lumix DMC-FH4K	Lumix DMC-FH4P
Lumix DMC-FH4S	Lumix DMC-FH5	Lumix DMC-FH5GK
Lumix DMC-FH5K	Lumix DMC-FH5N	Lumix DMC-FH5P
Lumix DMC-FH5S	Lumix DMC-FH5V	Lumix DMC-FH6
Lumix DMC-FH6A	Lumix DMC-FH6GK	Lumix DMC-FH6K
Lumix DMC-FH6P	Lumix DMC-FH6S	Lumix DMC-FH6Y
Lumix DMC-FH7	Lumix DMC-FH7GK	Lumix DMC-FH7K
Lumix DMC-FH7N	Lumix DMC-FH7P	Lumix DMC-FH7S
Lumix DMC-FH8	Lumix DMC-FH8GK	Lumix DMC-FH8K
Lumix DMC-FH8N	Lumix DMC-FH8R	Lumix DMC-FH8S
Lumix DMC-FH8V	Lumix DMC-FP5	Lumix DMC-FP5A
Lumix DMC-FP5G	Lumix DMC-FP5GK	Lumix DMC-FP5K
Lumix DMC-FP5P	Lumix DMC-FP5S	Lumix DMC-FP7
Lumix DMC-FP77	Lumix DMC-FP7A	Lumix DMC-FP7D
Lumix DMC-FP7GK	Lumix DMC-FP7K	Lumix DMC-FP7N
Lumix DMC-FP7P	Lumix DMC-FP7R	Lumix DMC-FP7S
Lumix DMC-FS14	Lumix DMC-FS16	Lumix DMC-FS16A
Lumix DMC-FS16K	Lumix DMC-FS16P	Lumix DMC-FS16R
Lumix DMC-FS16S	Lumix DMC-FS18	Lumix DMC-FS18K
Lumix DMC-FS18N	Lumix DMC-FS18P	Lumix DMC-FS18S
Lumix DMC-FS18V	Lumix DMC-FS22	Lumix DMC-FS22K
Lumix DMC-FS22N	Lumix DMC-FS22P	Lumix DMC-FS22S
Lumix DMC-FS28	Lumix DMC-FS28K	Lumix DMC-FS28P
Lumix DMC-FS28S	Lumix DMC-FS35	Lumix DMC-FS35A
Lumix DMC-FS35K	Lumix DMC-FS35R	Lumix DMC-FS35S
Lumix DMC-FS35V	Lumix DMC-FS37	Lumix DMC-FS37K
Lumix DMC-FS37R	Lumix DMC-FS37S	Lumix DMC-FS40
Lumix DMC-FS40A	Lumix DMC-FS40K	Lumix DMC-FS40P
Lumix DMC-FS40S	Lumix DMC-FS40Y	Lumix DMC-FS41
Lumix DMC-FS45	Lumix DMC-FS45K	Lumix DMC-FS45N
Lumix DMC-FS45R	Lumix DMC-FS45S	Lumix DMC-FS45V
Lumix DMC-FT20	Lumix DMC-FT20A	Lumix DMC-FT20D
Lumix DMC-FT20K	Lumix DMC-FT20R	Lumix DMC-FT25
Lumix DMC-FT25A	Lumix DMC-FT25K	Lumix DMC-FT25R
Lumix DMC-FT25W	Lumix DMC-FX77	Lumix DMC-FX77A
Lumix DMC-FX77K	Lumix DMC-FX77N	Lumix DMC-FX77P
Lumix DMC-FX77S	Lumix DMC-FX77W	Lumix DMC-FX78
Lumix DMC-FX78A	Lumix DMC-FX78GK	Lumix DMC-FX78K

Lumix DMC-FX78N	Lumix DMC-FX78P	Lumix DMC-FX78S
Lumix DMC-FX78W	Lumix DMC-FX80	Lumix DMC-FX80GK
Lumix DMC-FX80K	Lumix DMC-FX80N	Lumix DMC-FX80P
Lumix DMC-FX80V	Lumix DMC-FX80W	Lumix DMC-FX90
Lumix DMC-FX90K	Lumix DMC-S1	Lumix DMC-S1A
Lumix DMC-S1GK	Lumix DMC-S1K	Lumix DMC-S1N
Lumix DMC-S1P	Lumix DMC-S1S	Lumix DMC-S1W
Lumix DMC-S2	Lumix DMC-S2EB	Lumix DMC-S2EE
Lumix DMC-S2EF	Lumix DMC-S2EG	Lumix DMC-S2EP
Lumix DMC-S2GA	Lumix DMC-S2GC	Lumix DMC-S2GF
Lumix DMC-S2GK	Lumix DMC-S2GN	Lumix DMC-S2GT
Lumix DMC-S2K	Lumix DMC-S2P	Lumix DMC-S2PU
Lumix DMC-S2R	Lumix DMC-S2V	Lumix DMC-S2W
Lumix DMC-S3	Lumix DMC-S3A	Lumix DMC-S3EB-KA
Lumix DMC-S3EB-WA	Lumix DMC-S3GK	Lumix DMC-S3K
Lumix DMC-S3KKIT-2012	Lumix DMC-S3PA	Lumix DMC-S3R
Lumix DMC-S3V	Lumix DMC-S3W	Lumix DMC-S3WKIT-2012
Lumix DMC-S5	Lumix DMC-S5EB	Lumix DMC-S5EE
Lumix DMC-S5EF	Lumix DMC-S5EG	Lumix DMC-S5GA
Lumix DMC-S5GF	Lumix DMC-S5GN	Lumix DMC-S5K
Lumix DMC-S5R	Lumix DMC-S5S	Lumix DMC-SZ02
Lumix DMC-SZ1	Lumix DMC-SZ1A	Lumix DMC-SZ1GK
Lumix DMC-SZ1K	Lumix DMC-SZ1R	Lumix DMC-SZ1S
Lumix DMC-SZ1V	Lumix DMC-SZ5	Lumix DMC-SZ5GK
Lumix DMC-SZ5K	Lumix DMC-SZ5W	Lumix DMC-SZ7
Lumix DMC-SZ7GK	Lumix DMC-SZ7K	Lumix DMC-SZ7P
Lumix DMC-SZ7T	Lumix DMC-SZ7W	Lumix DMC-TS20
Lumix DMC-TS20A	Lumix DMC-TS20D	Lumix DMC-TS20GK
Lumix DMC-TS20K	Lumix DMC-TS20R	Lumix DMC-TS25
Lumix DMC-TS25A	Lumix DMC-TS25K	Lumix DMC-TS25R
Lumix DMC-TS25W		