

Gelius PRO
Model: GP-SW007

TACTICAL NAVY

MULTIFUNCTIONAL PROTECTED SMART WATCH

User Manual

Device maintenance

Please observe the following tips when using the smart watch:

- Do not forget to clean the smart watch, especially the inside, keep it dry.
- Adjust the tightness of the smartwatch on your wrist to allow air to circulate.
- Excessive application of creams, antiseptics and other skin care substances to the wrist before using the smart watch is prohibited.
- Please stop wearing the smart watch in case of allergy.

Getting to know the clock

Power/reset button
Touch display
Microphone
Speaker
Menu button
Controller

Note: Press and hold the power button to turn on the watch

Activation and charging of the watch

Before using the watch for the first time, it must be charged and activated. Using the magnetic charging cable, attach it to the metal charging slot on the back of the watch. The other end of the charging cable must be connected to the USB port of the charger.

1. Download and pair

After the watch is successfully paired with the phone, every time the app is launched, the watch will automatically connect to the phone and the data can be synchronized by opening the "Da Fit" app.

WARNING!

1.1 Press and hold the top "POWER" button to turn on the device.

1.2 Scan the QR code below to install the free app "Da Fit", or download "Da Fit" from the App Store, Google Play, and then install it.

1.3 Open the "Da Fit" mobile application, select the device to be paired from the device list (GP-SW007).

1.4 Turn on the mobile phone's Bluetooth and open the "Da Fit" APP, click "Add Device" to connect.

1.5 Turn on the phone menu on the watch as shown in the picture.

Then go to the mobile phone in the Bluetooth menu and connect (GP-SW007 Audio) in the device list. To use the functions of making and receiving incoming and outgoing calls.

PAIRING DEVICES
Audio SW007
Connected for calls and multimedia sound

Call function

PHONE: Open
RECENT CALL
DIAL PAD
CONTACT

135 6666 6666
1 2 3
4 5 6
7 8 9
0

09:30
135 6666 6666
08:22

DA FIT

2. Smart watch interface functions

When the watch is connected to your phone, you can use it to dial a number to make a call, or you can answer calls from your phone on the watch. However, the company reserves the right to constantly update the content of the products.

SPECIAL ATTENTION:
For other questions about using a smart watch, you can get detailed answers on the company's website or contact the contact where the device was purchased.

2.1 Interface (main screen)
2.1 Power on: Press and hold the top "POWER" button for 3 seconds to turn on the device.

2.2 Shutdown: In the interface, press the top "POWER" button for 3 seconds, then press the "!" icon to turn off the device.

2.3 Switch Watchface (Watchface): Press and hold the home screen interface until the selection menu appears. Choose from 5 proposed parameters (Watchface), your choice is the main one.

3. Smart watch functions

Operating instructions

SLEEP
LIUKE
Long time no see. How are you?
Let's have dinner tonight! I made an appointment with some old classmates in Shenzhen.

Music management
The watch can receive and display messages and reminders on the screen. When connected, the watch can control the phone's music player.

Message
The watch can record and display messages and reminders on the screen. You can enable or disable them in the app.

Pulse
The watch can record and display heart rate. Click on the heart rate interface to measure your current heart rate.

Weather information
The weather page displays the weather forecast and information about the situation for the following days of Sunday. For information about the weather, you need to connect the smart watch with the application.

Multifunctional sports modes
123 sports exercises to choose from will be available for selection. To set up your individual exercises, just go to the menu and click add exercise.

Blood pressure
Click on the blood pressure interface to measure the current blood pressure value. More detailed analysis and data records can be viewed in the appendix.

Voice assistant function
When using this function, the smart watch will help with any question or control of the smartphone. Just use the voice assistant if you want to use any function of the smartphone.

Explanation!
- All devices that are tested for moisture penetration and dust exposure are assigned a degree of protection. It consists of the two (IPXX) determines the degree of protection against the penetration of solid particles. The second digit in the degree of protection (IPXX) means the level of protection against water. In some cases, one of the numbers can be replaced by X. If the protection class IPX7 is specified, it will withstand the ingress of water jets, and it did not pass the test for protection against dust.

4. Functions in the DaFit application

Basic parameters

No	Content	Options
1	Model product	SW007
2	LCD	18", 280x320
3	CPU	GR5515+AC6959A
4	RAM + ROM	RAM 256KB+ROM 64M
5	Touch panel	Full touch screen
6	Bluetooth	5.0
7	Input	Permissible input current up to 1 A (5V) 500 mAh maximum
8	Operating temperature	vid. -20° C до +40° C
9	Battery	320 mAh
10	Water resistance rating	IP68
11	Compatible OS:	Android 4.4 + iOS 9.0 +
12	APP	DaFit

Explanation!
- For most problems with the operation and connection of the smartwatch, the easiest way is to restart the system. Therefore, in case of problems with the smart watch and smartphone, you need to restart both devices.

Explanation!
- This product is not a medical device. All measurement data and results are provided for reference only and may not be used for the professional diagnosis or monitoring of any medical condition. External factors (such as hair on the hands, tattoos or dark skin) can lead to inaccurate results or inability to perform measurements.

Explanation!
- All devices that are tested for moisture penetration and dust exposure are assigned a degree of protection. It consists of the two (IPXX) determines the degree of protection against the penetration of solid particles. The second digit in the degree of protection (IPXX) means the level of protection against water. In some cases, one of the numbers can be replaced by X. If the protection class IPX7 is specified, it will withstand the ingress of water jets, and it did not pass the test for protection against dust.

Explanation!
- Please consult a doctor before engaging in a new or any sport.
- The device is not a certified medical device, the measurement results of this product are for reference only and are not used for any medical indications.
- After connecting the charger, connect the USB cable (you can use a computer port or mobile power supply or charging adapter), the desired input voltage should not be exceeded 5V 1A.
- Bluetooth. Before you start connecting, make sure that Bluetooth is turned on in each device. Sometimes you may need to reconnect (turn off and on again) Bluetooth on your smartphone and smartwatch.
- After connecting the charger, connect the USB cable (you can use a computer port or mobile power supply or charging adapter), the desired input voltage should not be exceeded 5V 1A.
- Please do not subject the device to strong shocks.
- Please avoid direct sunlight or heaters.
- Do not disassemble or repair the device yourself.
- It is important to hand over packaging, batteries, accessories and other electronic products to specialized companies, or collect them in a special container in a designated place that is responsible for environmentally friendly methods of storage, treatment, disposal or disposal of hazardous waste.
- OS version. Outdated OS can also cause the clock to be out of sync with the phone. If you have a new operating system, you need to install it on a smart watch (having previously removed the current old version from the device). After downloading new software, you need to re-sync your phone.
- Disconnection due to phone settings. Some phone models often use a power consumption mode that optimizes power consumption. Inactive programs go to sleep, it becomes inactive. This may affect the background of the program. You can change the script in the smartphone settings. Remove restrictions or add an application to the list of exceptions.
- Bluetooth connectivity may be lost frequently if there are foreign objects (such as walls or other active Bluetooth devices) between the device carrier and the phone, if the media and phone are in a Wi-Fi environment, in an microwave oven.
- Phones from different manufacturers can be equipped with power-limiting mechanisms that prevent the application from running in the background or searching for available Bluetooth devices for reconnection.

Explanation!
- For most problems with the operation and connection of the smartwatch, the easiest way is to restart the system. Therefore, in case of problems with the smart watch and smartphone, you need to restart both devices.

Explanation!
- All devices that are tested for moisture penetration and dust exposure are assigned a degree of protection. It consists of the two (IPXX) determines the degree of protection against the penetration of solid particles. The second digit in the degree of protection (IPXX) means the level of protection against water. In some cases, one of the numbers can be replaced by X. If the protection class IPX7 is specified, it will withstand the ingress of water jets, and it did not pass the test for protection against dust.

Explanation!
- Please consult a doctor before engaging in a new or any sport.
- The device is not a certified medical device, the measurement results of this product are for reference only and are not used for any medical indications.
- After connecting the charger, connect the USB cable (you can use a computer port or mobile power supply or charging adapter), the desired input voltage should not be exceeded 5V 1A.
- Bluetooth. Before you start connecting, make sure that Bluetooth is turned on in each device. Sometimes you may need to reconnect (turn off and on again) Bluetooth on your smartphone and smartwatch.
- After connecting the charger, connect the USB cable (you can use a computer port or mobile power supply or charging adapter), the desired input voltage should not be exceeded 5V 1A.
- Please do not subject the device to strong shocks.
- Please avoid direct sunlight or heaters.
- Do not disassemble or repair the device yourself.
- It is important to hand over packaging, batteries, accessories and other electronic products to specialized companies, or collect them in a special container in a designated place that is responsible for environmentally friendly methods of storage, treatment, disposal or disposal of hazardous waste.
- OS version. Outdated OS can also cause the clock to be out of sync with the phone. If you have a new operating system, you need to install it on a smart watch (having previously removed the current old version from the device). After downloading new software, you need to re-sync your phone.
- Disconnection due to phone settings. Some phone models often use a power consumption mode that optimizes power consumption. Inactive programs go to sleep, it becomes inactive. This may affect the background of the program. You can change the script in the smartphone settings. Remove restrictions or add an application to the list of exceptions.
- Bluetooth connectivity may be lost frequently if there are foreign objects (such as walls or other active Bluetooth devices) between the device carrier and the phone, if the media and phone are in a Wi-Fi environment, in an microwave oven.
- Phones from different manufacturers can be equipped with power-limiting mechanisms that prevent the application from running in the background or searching for available Bluetooth devices for reconnection.

Explanation!
- For most problems with the operation and connection of the smartwatch, the easiest way is to restart the system. Therefore, in case of problems with the smart watch and smartphone, you need to restart both devices.

Explanation!
- All devices that are tested for moisture penetration and dust exposure are assigned a degree of protection. It consists of the two (IPXX) determines the degree of protection against the penetration of solid particles. The second digit in the degree of protection (IPXX) means the level of protection against water. In some cases, one of the numbers can be replaced by X. If the protection class IPX7 is specified, it will withstand the ingress of water jets, and it did not pass the test for protection against dust.

Explanation!
- Please consult a doctor before engaging in a new or any sport.
- The device is not a certified medical device, the measurement results of this product are for reference only and are not used for any medical indications.
- After connecting the charger, connect the USB cable (you can use a computer port or mobile power supply or charging adapter), the desired input voltage should not be exceeded 5V 1A.
- Bluetooth. Before you start connecting, make sure that Bluetooth is turned on in each device. Sometimes you may need to reconnect (turn off and on again) Bluetooth on your smartphone and smartwatch.
- After connecting the charger, connect the USB cable (you can use a computer port or mobile power supply or charging adapter), the desired input voltage should not be exceeded 5V 1A.
- Please do not subject the device to strong shocks.
- Please avoid direct sunlight or heaters.
- Do not disassemble or repair the device yourself.
- It is important to hand over packaging, batteries, accessories and other electronic products to specialized companies, or collect them in a special container in a designated place that is responsible for environmentally friendly methods of storage, treatment, disposal or disposal of hazardous waste.
- OS version. Outdated OS can also cause the clock to be out of sync with the phone. If you have a new operating system, you need to install it on a smart watch (having previously removed the current old version from the device). After downloading new software, you need to re-sync your phone.
- Disconnection due to phone settings. Some phone models often use a power consumption mode that optimizes power consumption. Inactive programs go to sleep, it becomes inactive. This may affect the background of the program. You can change the script in the smartphone settings. Remove restrictions or add an application to the list of exceptions.
- Bluetooth connectivity may be lost frequently if there are foreign objects (such as walls or other active Bluetooth devices) between the device carrier and the phone, if the media and phone are in a Wi-Fi environment, in an microwave oven.
- Phones from different manufacturers can be equipped with power-limiting mechanisms that prevent the application from running in the background or searching for available Bluetooth devices for reconnection.

Explanation!
- For most problems with the operation and connection of the smartwatch, the easiest way is to restart the system. Therefore, in case of problems with the smart watch and smartphone, you need to restart both devices.

Explanation!
- All devices that are tested for moisture penetration and dust exposure are assigned a degree of protection. It consists of the two (IPXX) determines the degree of protection against the penetration of solid particles. The second digit in the degree of protection (IPXX) means the level of protection against water. In some cases, one of the numbers can be replaced by X. If the protection class IPX7 is specified, it will withstand the ingress of water jets, and it did not pass the test for protection against dust.

Explanation!
- Please consult a doctor before engaging in a new or any sport.
- The device is not a certified medical device, the measurement results of this product are for reference only and are not used for any medical indications.
- After connecting the charger, connect the USB cable (you can use a computer port or mobile power supply or charging adapter), the desired input voltage should not be exceeded 5V 1A.
- Bluetooth. Before you start connecting, make sure that Bluetooth is turned on in each device. Sometimes you may need to reconnect (turn off and on again) Bluetooth on your smartphone and smartwatch.
- After connecting the charger, connect the USB cable (you can use a computer port or mobile power supply or charging adapter), the desired input voltage should not be exceeded 5V 1A.
- Please do not subject the device to strong shocks.
- Please avoid direct sunlight or heaters.
- Do not disassemble or repair the device yourself.
- It is important to hand over packaging, batteries, accessories and other electronic products to specialized companies, or collect them in a special container in a designated place that is responsible for environmentally friendly methods of storage, treatment, disposal or disposal of hazardous waste.
- OS version. Outdated OS can also cause the clock to be out of sync with the phone. If you have a new operating system, you need to install it on a smart watch (having previously removed the current old version from the device). After downloading new software, you need to re-sync your phone.
- Disconnection due to phone settings. Some phone models often use a power consumption mode that optimizes power consumption. Inactive programs go to sleep, it becomes inactive. This may affect the background of the program. You can change the script in the smartphone settings. Remove restrictions or add an application to the list of exceptions.
- Bluetooth connectivity may be lost frequently if there are foreign objects (such as walls or other active Bluetooth devices) between the device carrier and the phone, if the media and phone are in a Wi-Fi environment, in an microwave oven.
- Phones from different manufacturers can be equipped with power-limiting mechanisms that prevent the application from running in the background or searching for available Bluetooth devices for reconnection.

Explanation!
- For most problems with the operation and connection of the smartwatch, the easiest way is to restart the system. Therefore, in case of problems with the smart watch and smartphone, you need to restart both devices.

Explanation!
- All devices that are tested for moisture penetration and dust exposure are assigned a degree of protection. It consists of the two (IPXX) determines the degree of protection against the penetration of solid particles. The second digit in the degree of protection (IPXX) means the level of protection against water. In some cases, one of the numbers can be replaced by X. If the protection class IPX7 is specified, it will withstand the ingress of water jets, and it did not pass the test for protection against dust.

Explanation!
- Please consult a doctor before engaging in a new or any sport.
- The device is not a certified medical device, the measurement results of this product are for reference only and are not used for any medical indications.
- After connecting the charger, connect the USB cable (you can use a computer port or mobile power supply or charging adapter), the desired input voltage should not be exceeded 5V 1A.
- Bluetooth. Before you start connecting, make sure that Bluetooth is turned on in each device. Sometimes you may need to reconnect (turn off and on again) Bluetooth on your smartphone and smartwatch.
- After connecting the charger, connect the USB cable (you can use a computer port or mobile power supply or charging adapter), the desired input voltage should not be exceeded 5V 1A.
- Please do not subject the device to strong shocks.
- Please avoid direct sunlight or heaters.
- Do not disassemble or repair the device yourself.
- It is important to hand over packaging, batteries, accessories and other electronic products to specialized companies, or collect them in a special container in a designated place that is responsible for environmentally friendly methods of storage, treatment, disposal or disposal of hazardous waste.
- OS version. Outdated OS can also cause the clock to be out of sync with the phone. If you have a new operating system, you need to install it on a smart watch (having previously removed the current old version from the device). After downloading new software, you need to re-sync your phone.
- Disconnection due to phone settings. Some phone models often use a power consumption mode that optimizes power consumption. Inactive programs go to sleep, it becomes inactive. This may affect the background of the program. You can change the script in the smartphone settings. Remove restrictions or add an application to the list of exceptions.
- Bluetooth connectivity may be lost frequently if there are foreign objects (such as walls or other active Bluetooth devices) between the device carrier and the phone, if the media and phone are in a Wi-Fi environment, in an microwave oven.
- Phones from different manufacturers can be equipped with power-limiting mechanisms that prevent the application from running in the background or searching for available Bluetooth devices for reconnection.

Gelius PRO
Model: GP-SW007

TACTICAL NAVY
MULTIFUNCTIONAL PROTECTED SMART WATCH

Instrukcja obsługi

Konserwacja urządzeń

1. Pobierz i sparuj

Podczas korzystania z inteligentnego zegarka należy przestrzegać następujących wskazówek:

- Nie zapomnij wyczyścić inteligentnego zegarka, zwłaszcza wewnątrz, utrzymuj go w suchości.
- Żeżeskanu poniżej kod QR, aby zaistalować bezpłatną aplikację „Da Fit” lub pobierz „Da Fit” z App Store, Google Play, a następnie zaistaluj.
- Nadmierne nakładanie kremów, środków antyseptycznych i innych substancji pieleguracyjnych na nadgarstek przed użyciem smartwatcha jest zabronione.
- Prześtań nosić inteligentny zegarek w przypadku alergii lub dyskomfortu.
- Otwórz aplikację mobilną „Da Fit”, wybierz urządzenie do sparowania z listy urządzeń (GP-SW007).
- Włącz Bluetooth telefonu komórkowego i otwórz aplikację „Da Fit”, aby się połączyć.

Zapoznanie się z zegarem

Uwaga: Naciśnij i przytrzymaj przycisk zasilania, aby włączyć zegarek

Aktywacja i ładowanie zegarka

Przed pierwszym użyciem zegarka należy go ładować i aktywować. Za pomocą magnetycznego kabla ładowającego podłącz do metalowego gniazda ładowania z tyłu zegarka. Drugi koniec kabla ładowania musi być podłączony do portu USB ładowarki.

Informacje techniczne (Kod)

```

KOD: M0V-ND2-1.6.1
MAC ADDRESS: F9A3141C5994
0F49526
T0-B60602151
KOD: Audio
  
```

Konserwacja urządzeń

1. Pobierz i sparuj

Podczas korzystania z inteligentnego zegarka należy przestrzegać następujących wskazówek:

- Nie zapomnij wyczyścić inteligentnego zegarka, zwłaszcza wewnątrz, utrzymuj go w suchości.
- Żeżeskanu poniżej kod QR, aby zaistalować bezpłatną aplikację „Da Fit” lub pobierz „Da Fit” z App Store, Google Play, a następnie zaistaluj.
- Nadmierne nakładanie kremów, środków antyseptycznych i innych substancji pieleguracyjnych na nadgarstek przed użyciem smartwatcha jest zabronione.
- Prześtań nosić inteligentny zegarek w przypadku alergii lub dyskomfortu.
- Otwórz aplikację mobilną „Da Fit”, wybierz urządzenie do sparowania z listy urządzeń (GP-SW007).
- Włącz Bluetooth telefonu komórkowego i otwórz aplikację „Da Fit”, aby się połączyć.

Zapoznanie się z zegarem

Uwaga: Naciśnij i przytrzymaj przycisk zasilania, aby włączyć zegarek

Aktywacja i ładowanie zegarka

Przed pierwszym użyciem zegarka należy go ładować i aktywować. Za pomocą magnetycznego kabla ładowającego podłącz do metalowego gniazda ładowania z tyłu zegarka. Drugi koniec kabla ładowania musi być podłączony do portu USB ładowarki.

Konserwacja urządzeń

1. Pobierz i sparuj

Podczas korzystania z inteligentnego zegarka należy przestrzegać następujących wskazówek:

- Nie zapomnij wyczyścić inteligentnego zegarka, zwłaszcza wewnątrz, utrzymuj go w suchości.
- Żeżeskanu poniżej kod QR, aby zaistalować bezpłatną aplikację „Da Fit” lub pobierz „Da Fit” z App Store, Google Play, a następnie zaistaluj.
- Nadmierne nakładanie kremów, środków antyseptycznych i innych substancji pieleguracyjnych na nadgarstek przed użyciem smartwatcha jest zabronione.
- Prześtań nosić inteligentny zegarek w przypadku alergii lub dyskomfortu.
- Otwórz aplikację mobilną „Da Fit”, wybierz urządzenie do sparowania z listy urządzeń (GP-SW007).
- Włącz Bluetooth telefonu komórkowego i otwórz aplikację „Da Fit”, aby się połączyć.

Zapoznanie się z zegarem

Uwaga: Naciśnij i przytrzymaj przycisk zasilania, aby włączyć zegarek

Aktywacja i ładowanie zegarka

Przed pierwszym użyciem zegarka należy go ładować i aktywować. Za pomocą magnetycznego kabla ładowującego podłącz do metalowego gniazda ładowania z tyłu zegarka. Drugi koniec kabla ładowania musi być podłączony do portu USB ładowarki.

Konserwacja urządzeń

1. Pobierz i sparuj

Podczas korzystania z inteligentnego zegarka należy przestrzegać następujących wskazówek:

- Nie zapomnij wyczyścić inteligentnego zegarka, zwłaszcza wewnątrz, utrzymuj go w suchości.
- Żeżeskanu poniżej kod QR, aby zaistalować bezpłatną aplikację „Da Fit” lub pobierz „Da Fit” z App Store, Google Play, a następnie zaistaluj.
- Nadmierne nakładanie kremów, środków antyseptycznych i innych substancji pieleguracyjnych na nadgarstek przed użyciem smartwatcha jest zabronione.
- Prześtań nosić inteligentny zegarek w przypadku alergii lub dyskomfortu.
- Otwórz aplikację mobilną „Da Fit”, wybierz urządzenie do sparowania z listy urządzeń (GP-SW007).
- Włącz Bluetooth telefonu komórkowego i otwórz aplikację „Da Fit”, aby się połączyć.

Zapoznanie się z zegarem

Uwaga: Naciśnij i przytrzymaj przycisk zasilania, aby włączyć zegarek

Aktywacja i ładowanie zegarka

Przed pierwszym użyciem zegarka należy go ładować i aktywować. Za pomocą magnetycznego kabla ładowującego podłącz do metalowego gniazda ładowania z tyłu zegarka. Drugi koniec kabla ładowania musi być podłączony do portu USB ładowarki.

Konserwacja urządzeń

1. Pobierz i sparuj

Podczas korzystania z inteligentnego zegarka należy przestrzegać następujących wskazówek:

- Nie zapomnij wyczyścić inteligentnego zegarka, zwłaszcza wewnątrz, utrzymuj go w suchości.
- Żeżeskanu poniżej kod QR, aby zaistalować bezpłatną aplikację „Da Fit” lub pobierz „Da Fit” z App Store, Google Play, a następnie zaistaluj.
- Nadmierne nakładanie kremów, środków antyseptycznych i innych substancji pieleguracyjnych na nadgarstek przed użyciem smartwatcha jest zabronione.
- Prześtań nosić inteligentny zegarek w przypadku alergii lub dyskomfortu.
- Otwórz aplikację mobilną „Da Fit”, wybierz urządzenie do sparowania z listy urządzeń (GP-SW007).
- Włącz Bluetooth telefonu komórkowego i otwórz aplikację „Da Fit”, aby się połączyć.

Zapoznanie się z zegarem

Uwaga: Naciśnij i przytrzymaj przycisk zasilania, aby włączyć zegarek

Aktywacja i ładowanie zegarka

Przed pierwszym użyciem zegarka należy go ładować i aktywować. Za pomocą magnetycznego kabla ładowującego podłącz do metalowego gniazda ładowania z tyłu zegarka. Drugi koniec kabla ładowania musi być podłączony do portu USB ładowarki.

Konserwacja urządzeń

1. Pobierz i sparuj

Podczas korzystania z inteligentnego zegarka należy przestrzegać następujących wskazówek:

- Nie zapomnij wyczyścić inteligentnego zegarka, zwłaszcza wewnątrz, utrzymuj go w suchości.
- Żeżeskanu poniżej kod QR, aby zaistalować bezpłatną aplikację „Da Fit” lub pobierz „Da Fit” z App Store, Google Play, a następnie zaistaluj.
- Nadmierne nakładanie kremów, środków antyseptycznych i innych substancji pieleguracyjnych na nadgarstek przed użyciem smartwatcha jest zabronione.
- Prześtań nosić inteligentny zegarek w przypadku alergii lub dyskomfortu.
- Otwórz aplikację mobilną „Da Fit”, wybierz urządzenie do sparowania z listy urządzeń (GP-SW007).
- Włącz Bluetooth telefonu komórkowego i otwórz aplikację „Da Fit”, aby się połączyć.

Zapoznanie się z zegarem

Uwaga: Naciśnij i przytrzymaj przycisk zasilania, aby włączyć zegarek

Aktywacja i ładowanie zegarka

Przed pierwszym użyciem zegarka należy go ładować i aktywować. Za pomocą magnetycznego kabla ładowującego podłącz do metalowego gniazda ładowania z tyłu zegarka. Drugi koniec kabla ładowania musi być podłączony do portu USB ładowarki.

Konserwacja urządzeń

1. Pobierz i sparuj

Podczas korzystania z inteligentnego zegarka należy przestrzegać następujących wskazówek:

- Nie zapomnij wyczyścić inteligentnego zegarka, zwłaszcza wewnątrz, utrzymuj go w suchości.
- Żeżeskanu poniżej kod QR, aby zaistalować bezpłatną aplikację „Da Fit” lub pobierz „Da Fit” z App Store, Google Play, a następnie zaistaluj.
- Nadmierne nakładanie kremów, środków antyseptycznych i innych substancji pieleguracyjnych na nadgarstek przed użyciem smartwatcha jest zabronione.
- Prześtań nosić inteligentny zegarek w przypadku alergii lub dyskomfortu.
- Otwórz aplikację mobilną „Da Fit”, wybierz urządzenie do sparowania z listy urządzeń (GP-SW007).
- Włącz Bluetooth telefonu komórkowego i otwórz aplikację „Da Fit”, aby się połączyć.

Zapoznanie się z zegarem

Uwaga: Naciśnij i przytrzymaj przycisk zasilania, aby włączyć zegarek

Aktywacja i ładowanie zegarka

Przed pierwszym użyciem zegarka należy go ładować i aktywować. Za pomocą magnetycznego kabla ładowującego podłącz do metalowego gniazda ładowania z tyłu zegarka. Drugi koniec kabla ładowania musi być podłączony do portu USB ładowarki.

Konserwacja urządzeń

1. Pobierz i sparuj

Podczas korzystania z inteligentnego zegarka należy przestrzegać następujących wskazówek:

- Nie zapomnij wyczyścić inteligentnego zegarka, zwłaszcza wewnątrz, utrzymuj go w suchości.
- Żeżeskanu poniżej kod QR, aby zaistalować bezpłatną aplikację „Da Fit” lub pobierz „Da Fit” z App Store, Google Play, a następnie zaistaluj.
- Nadmierne nakładanie kremów, środków antyseptycznych i innych substancji pieleguracyjnych na nadgarstek przed użyciem smartwatcha jest zabronione.
- Prześtań nosić inteligentny zegarek w przypadku alergii lub dyskomfortu.
- Otwórz aplikację mobilną „Da Fit”, wybierz urządzenie do sparowania z listy urządzeń (GP-SW007).
- Włącz Bluetooth telefonu komórkowego i otwórz aplikację „Da Fit”, aby się połączyć.

Zapoznanie się z zegarem

Uwaga: Naciśnij i przytrzymaj przycisk zasilania, aby włączyć zegarek

Aktywacja i ładowanie zegarka

Przed pierwszym użyciem zegarka należy go ładować i aktywować. Za pomocą magnetycznego kabla ładowującego podłącz do metalowego gniazda ładowania z tyłu zegarka. Drugi koniec kabla ładowania musi być podłączony do portu USB ładowarki.