

Совместим с:

Для Asus

UX31 Ultrabook

UX31A

UX31A Ultrabook

UX31E Ultrabook

UX31E-DH72

UX31E-RY018X

ZENBOOK UX31

Zenbook UX31A

ZENBOOK UX31E

Для Asus Ux31 серии

UX31 серии

UX31A-1A

UX31A-2A

UX31A-2D

UX31E-1A

UX31E-1B

UX31E-1C

UX31E-DH52

UX31E-DH53

UX31e-ma1

UX31e-mt1

UX31E-RSL8

UX31E-RY003V

UX31E-RY009V

UX31E-RY010V

UX31E-RY010X

UX31E-RY012V

UX31E-RY024V

UX31E-RY256S

UX31E-sh72

UX31E-xh51

UX31E-xh71

UX31E-xh72

X31E-RY029V

Для Asus Zenbook серии

UX31, UX31E

Для Asus Zenbook Ux31 серия

Zenbook UX31A-C4027H

Zenbook UX31A-C4029H

Zenbook UX31A-C4032H

Zenbook UX31A-C4033H

Zenbook UX31A-R4002H

Zenbook UX31A-R4002V

Zenbook UX31A-R4003H

Zenbook UX31A-R4003P

Zenbook UX31A-R4003V

Zenbook UX31A-R4003X

Zenbook UX31A-R4004H

Zenbook UX31A-R4004V

Zenbook UX31A-R4005H

Zenbook UX31A-R4005V

Zenbook UX31E-1A

Zenbook UX31E-1C

Zenbook UX31E-RY008V

Zenbook UX31E-RY009V

Zenbook UX31E-RY010V

Zenbook UX31E-RY012V

Zenbook UX31E-RY029V