

Совместим с:

LG LM40 Series,
LG LM50 Series,
LG LM60 Series

LG LM Series

LE50, LM60, LM60-3B5C1,
LM60-CBJA, LM60 Express,
LM70, LM70 Express, LM70-QKXA

LG LS Series

LS45, LS55, LS55-1EFA,
LS55-1GJA, LS55 Express,
LS70, LS70 Express, LS75, LS75 Express

LG LS50 Series

LS50-AGHU1, LS50-AGHF1

LG LW Series

LW60, LW60-B3M44A, LW60-BAJA,
LW60-D2JA, LW60-DBJA, LW60 Express,
LW60-QCMA, LW70, LW70 Express,
LW70-QJMA, LW70-QLZA

LG LW40 Series

LW40 Express

LG LW65 Series

LW65 Express

LG LW75 Series

LW75 Express

LG R1 Series

R1 Pro Express Dual, R1-C001A9, R1-C002A9

LG R400 Series

R400-EP23A3, R400-MP22A3, R400-5222A3,
R400-52HGP1

LG R405 Series

R405, R405-G.CBB1A9, R405-G.CPB1A9,
R405-G.CPBSA9, R405-S.CPCBG, R405-S.CPCDG,
R405-GB02A9, R405-GP01A9, R405-SPCAG

LG RD400 Series

RD400-5D2A2

LG S1 Series

S1 Express Dual, S1 Pro Express Dual

LG T1 Series

T1 Express Dual

LG V1 Series

V1-W4WHV