

Совместим с:

Lenovo Flex 5-1470, Lenovo Flex 5-1570, Lenovo Yoga 520, Lenovo IdeaPad 320S-14IKB (Type 80X4), Lenovo IdeaPad 320S-14IKB (Type 81BN), Lenovo IdeaPad 520S-14IKB (Type 81BL), Lenovo IdeaPad 520S-14IKB (Type 80X2), Lenovo IdeaPad 320-15AST (Type 80YB), Lenovo IdeaPad 320S-15IKB (Type 80X5), Lenovo IdeaPad 320S-15ABR (Type 80YA), Lenovo IdeaPad 320S-15ABR (Type 80YB), Lenovo IdeaPad 320S-15IKB (Type 81BQ), Lenovo Yoga 520-14IKB (Type 80X8) IdeaPad, Lenovo Yoga 520-14IKB (Type 81C8) IdeaPad, Lenovo Yoga 520-14IKB (80X8), Lenovo Yoga 520-14IKB (80YM), Lenovo Yoga 520-14IKB (81C8), Lenovo Flex 5-1470 (Type 81C9), Lenovo Flex 5-1570 (Type 81CA), Lenovo Flex 5-1470 (Type 80XA), Lenovo Flex 5-1570 (Type 80XB), Lenovo 320S-15AST (ideapad) 80YB, Lenovo IdeaPad 320S-15ISK, Lenovo 320S-14IKB (Type 80X4) (ideapad), Lenovo 320S-15IKB (Type 80X5) (ideapad), Lenovo 320S-15ISK (ideapad), Lenovo 320S-15ABR, Lenovo 320S-15ABR 80Y9, Lenovo 520S-14IKB (Type 81BL), Lenovo 320S-14IKB (Type 81BN), Lenovo 320S-15IKB (Type 81BQ), Lenovo Flex 4-1470 Series, Lenovo Flex 4-1480 Series, Lenovo Flex 4-1570 Series, Lenovo Yoga 510-14IKB, Lenovo Yoga 510-14IKS, Lenovo 80YB, Lenovo 80X2, Lenovo 80X4, Lenovo 80X5, Lenovo 80X8, Lenovo 80XA, Lenovo 80XB, Lenovo 80Y9, Lenovo 80YA, Lenovo 81BL, Lenovo 81CA, Lenovo 81BN, Lenovo 81BQ, Lenovo 81C8, Lenovo 81C9.